

Bagged Water Installation



- Remove blue water bag from the clear outer bag. Place empty bag in recycling bin



- Firmly grip the top of the blue water bag in each hand creating "rabbit ears"



- With one positive action lower it onto the probe ensuring the 2 holes in the probe are visible in the water bag and release



- Replace cover



CLEAR ARCTIC SPRINGS

Keeping You wet on the inside[®]

920-7821



- To remove empty bag, push down firmly on the plate with one hand, and pull the empty bag off of the probe. Ensure no plastic residue is left on the probe area.
- Place empty water bag in recycling bin